



SATSOFT Installation Notes v 2.7

SATSOFT v 2.7 comes in two different builds, depending upon what type of license you have. Two install buttons are provided on the cd installation menu, one for node-locked, one for network client. Both of these options are described below.

If you already have SATSOFT installed on your computer and are upgrading to v 2.7, please follow the directions under *Upgrading to v 2.7*. If you have just purchased a license and are installing SATSOFT for the first time, please see *New Installations*.

Upgrading to v 2.7

It is usually best to uninstall the old version of SATSOFT first. Open Windows Explorer and navigate to your Program Files | SATSOFT directory. Double-click on setup.exe, select *Remove All Components*, and then click on Finish. Then, delete all of the files in the directory **except** the directory 5356-8651-2029-7641-5706. This contains your license files. Again, **do not delete** 5356-8651-2029-7641-5706. Your existing license files will be used - you do **not** need to obtain a new license key.

Insert your v 2.7 cd. When the menu appears (double click on Launch.exe if it does not) click on *Install SATSOFT* if you have a node-locked license, or *Install SATSOFT Client* if you will be connecting to a network license. For network clients, you will need to know the IP address and port of the computer hosting the SATSOFT license server.

New Installations

Insert your v 2.7 cd. When the menu appears (double click on Launch.exe if it does not) click on *Install SATSOFT* if you have a node-locked license, or *Install SATSOFT Client* if you have a network license.

Upon first-time installation of the SATSOFT node-locked version, you will be provided with a 30-day evaluation license, with several options enabled. *Help / License Manager* provides information on the options that are enabled, the expiration date, serial number (if you have purchased a license) and other information related to your license.

To obtain a key for single user (node-locked) licenses, start SATSOFT, and select *Help / License Manager* if the license manager dialog does not open automatically. Click on *Request Key*, and then *Register by e-mail*. If you don't have a mail client on your machine, email the *Reference Code* to support@satsoft.com. We will send you a key by email. Be sure to include your name, organization, telephone number, and serial number in the body of the email. You will find your serial number written on the CD label.

If, after obtaining your permanent key, you need to move the software to another machine, follow the procedure below:

1. Install SATSOFT on the new machine, select Help | License Manager, click on Request Key, and copy the Reference Code into a file, or write it on a piece of paper.
2. Then, start SATSOFT on the old machine (where the valid license is kept), select Help | License Manager, then click on Move License. Enter the reference code from step one above, and click on Generate. Copy/paste the License Key that was generated to a file, and move that back over to the new machine. Enter the key into the License Key field, enter your Serial Number, and click on OK.
3. If, when you clicked on Move License in step 2, a dialog reports that the license is not moveable, then click on Terminate License instead. Copy/paste the termination code and the Reference code from step one into an email (or click on Register by email from the new machine) to support@satsoft.com. After we receive this information, we can issue a key for the new machine.

Please see the License Manager chapter in your reference manual or in the on-line help for detailed instructions.

Network Server

To install the network server daemon, follow the procedure described in the readme.wri file on the CD. This can also be accessed from <http://www.satsoft.com/downloads/readme.wri>.